



SPECIFICATIONS

Dimensions

See Figure 2

Weight

0.68 kg (1.5 lbs) net

0.91 kg (2.0 lbs) packaged

REPLACEMENT PARTS AND ACCESSORIES

Cable (10 ft).....C121

Base Plate Bumpers.....80A8053A

GENERAL

The Shure A412B microphone base allows gooseneck microphones to be quickly mounted in situations where permanent installation is impractical. The angled XLR input connector maintains a low profile, while inside the base there is ample room for custom circuitry.


INSTALLATION

Attaching a Microphone to the Base


Insert the XLR connector on the microphone into the female XLR connector on the top of the microphone base.

Securing the Microphone Base to a Surface (Optional)


1. Install two No. 6 wood screws, two inches apart, on the mounting surface (see Figure 1, diagram A).
2. Place the key holes over the screw heads and push the microphone into position. Adjust the height of the screws as necessary to secure the microphone (see Figure 1, diagram B).



DIMENSIONS
FIGURE 2



SECURING THE A412B TO A MOUNTING SURFACE
FIGURE 1



REMOVING THE BACK PLATE
FIGURE 3

Distributed by

Jay S. Stanley & Associates

Connecting Presenters with Audiences

Sight | Sound | Knowledge

(501) 758-8029 | (888) 758-4728

www.jaystanley.com

SHURE®

*SHURE Incorporated <http://www.shure.com>
United States, Canada, Latin America, Caribbean:
5800 W. Touhy Avenue, Niles, IL 60714-4608, U.S.A.
Phone: 847-600-2000 U.S. Fax: 847-600-1212 Intl Fax: 847-600-6446
Europe, Middle East, Africa:
Shure Europe GmbH, Phone: 49-7131-72140 Fax: 49-7131-721414
Asia, Pacific:
Shure Asia Limited, Phone: 852-2893-4290 Fax: 852-2893-4055*